

HDNissan **V10.01** Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
ALMERA	N16	08/2009 *	Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		

HDNissan **V10.01** Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
			Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
ALMERA	N15	*	AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
			Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
ALMERA	L31	2006 2005 2004 2003 2002 2001 *	ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				

HDNissan **V10.01** Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
			Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			

HDNissan V10.01 Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
ALMERA	L30	2000 1999 1998 1997 *	Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			

HDNissan **V10.01** Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
			Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			

HDNissan V10.01 Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
ARMADA	TA60	2007 2006 2005 08/2006 10/2004 08/2003	EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
			Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
ATLEON	TKO	01/2004 05/2001 10/1999	E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
BASSARA	JU30	*	Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		

HDNissan **V10.01** Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
			Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
BLUEBIRD	U34	*	AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		

HDNissan **V10.01** Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
			Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
BLUEBIRD	U13	*	ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				

HDNissan **V10.01** Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
			Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
CABSTAR	TLO	12/2003	Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			

HDNissan **V10.01** Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
			Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
CABSTAR E	TLO	05/2001 11/1998	EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
		08/2007	Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	

HDNissan **V10.01** Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
CARAVAN	E25	12/2005	E-4WD	√	√	√	√	√	1.Freeze Frame(*)	
		08/2004							2.Can Diag Support Mntr (*)	
		05/2003	I-KEY	√	√	√	√	√	1.Work Support(*)	
		09/2002	DIU		√	√	√			
		11/2001	ASD	√	√	√	√	√		
		04/2001	PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	

HDNissan V10.01 Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
CEDRIC	Y31	08/2009 07/2007 11/2005 01/2004 08/1999 06/1998 09/1996	Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		

HDNissan V10.01 Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
		08/1995	PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
			Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
CEDRIC TAXI	Y31	*	AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
			Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
CEDRIC/G LORIA	Y34	*	ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				

HDNissan **V10.01** Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
			Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
CEDRIC/G LORIA	Y33	*	Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			

HDNissan **V10.01** Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
			Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
CIVILIAN	W41	12/2005 09/2004 10/2002 11/1999 02/1999 09/2009 07/2007 08/2004 11/2002 02/2000 04/1994	EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
		07/2007	Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
CREW	K30	11/2005	E-4WD	√	√	√	√	√	1.Freeze Frame(*)	
		06/2002							2.Can Diag Support Mntr (*)	
		08/1999	I-KEY	√	√	√	√	√	1.Work Support(*)	
		06/1998	DIU		√	√	√			
		09/1996	ASD	√	√	√	√	√		
		01/1996	PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
cube3	Z11	12/2006 05/2005 09/2003	Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		

HDNissan **V10.01** Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
			Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	

HDNissan V10.01 Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
ELGRAND	E51	09/2008 06/2007 12/2006 11/2005 08/2004 08/2003 05/2002	AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		

HDNissan **V10.01** Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
			Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
ELGRAND	E50	*	ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				

HDNissan **V10.01** Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
			Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
FRONTIER /NAVARA	D40	12/2006	Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			

HDNissan **V10.01** Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
			Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
INFINITI QX56	JA60	2007 2006 2005 2004 08/2006 10/2004	EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
		05/2007 08/2005 07/2003 02/2002	Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	

HDNissan **V10.01** Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
MARCH	K12	02/2002								
		05/2008	E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
		06/2007	I-KEY	√	√	√	√	√	1.Work Support(*)	
		10/2005	DIU		√	√	√			
		04/2004	ASD	√	√	√	√	√		
		06/2003	PRECRASH	√	√	√	√			
		06/2003	AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
		07/2002	4WD	√	√	√	√	√	1.Work Support(*)	
		*	4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
MARCH	K11	*	Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
			Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	

HDNissan V10.01 Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
MARCH/ MICRA	K12	05/2008 06/2007 03/2006 07/2002 10/2005 04/2004 06/2003	AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
			Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	

HDNissan V10.01 Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
MARCH/ MICRA	K11	*	ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				

HDNissan **V10.01** Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
			Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
MAXIMA/ CEFIRO	A33	01/1999	Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
			Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
MAXIMA/ CEFIRO	J31	12/2005 09/2003	EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
MAXIMA/ CEFIRO	J32	01/2009 02/2008	Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.DTC&SRT CONFIRMATION	
			AT	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			HVAC	√	√	√	√	√	1.Work Support(*)	
			MULTI AV	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	

HDNissan V10.01 Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
MICRA	K12	11/2002 03/2006 04/2004	AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		

HDNissan **V10.01** Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
			Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	

HDNissan V10.01 Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
MICRA	K11	*	ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				

HDNissan **V10.01** Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
			Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
MISTRAL	R20	*	Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			

HDNissan **V10.01** Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
		2007	Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			

HDNissan **V10.01** Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
MURANO	Z50	2006	EPS	√	√	√	√		1.Work Support(*)	
		2005	IPDM	√	√	√	√	√		
		2004	AIR PRESSURE MONITOR	√	√	√	√			
		2003	HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
		05/2007	E-4WD	√	√	√	√	√	1.Freeze Frame(*)	
		09/2004							2.Can Diag Support Mntr (*)	
		03/2007	I-KEY	√	√	√	√	√	1.Work Support(*)	
		11/2004	DIU		√	√	√			
		04/2003	ASD	√	√	√	√	√		
		12/2006	PRECRASH	√	√	√	√			
		11/2005	AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
		05/2005	4WD	√	√	√	√	√	1.Work Support(*)	
		03/2003	4WAS/RAS/HICAS	√	√	√	√	√		
		*	SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
			Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
NAVARA	D40	05/2007	E-4WD	√	√	√	√	√	1.Freeze Frame(*)	
		07/2006							2.Can Diag Support Mntr (*)	
		01/2005	I-KEY	√	√	√	√	√	1.Work Support(*)	
		09/2006	DIU		√	√	√			
		06/2005	ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	

HDNissan V10.01 Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
PALADIN	D22W	03/2003	Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		

HDNissan **V10.01** Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
			Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	

HDNissan **V10.01** Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
PATHFINDER ER ALMADA	TA60	2004	AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		

HDNissan **V10.01** Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
			Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	

HDNissan V10.01 Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
PATROL	Y61	12/2006 07/2004 10/2002 06/2001 02/2000 12/1997 07/2007 07/2006 10/2005 04/2004 08/2003 12/2002 09/2001 03/2000 08/1998 10/1997	ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
			Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
PATROL Pickup	UY61	08/2007 12/2006	Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			

HDNissan **V10.01** Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
			Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
PICKUP	D21	*	EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
		09/2004	Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	

HDNissan **V10.01** Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
PICKUP	D22	10/2003	E-4WD	√	√	√	√	√	1.Freeze Frame(*)	
		03/2003							2.Can Diag Support Mntr (*)	
		11/2001	I-KEY	√	√	√	√	√	1.Work Support(*)	
		05/1999	DIU		√	√	√			
		02/1998	ASD	√	√	√	√	√		
		*	PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	

HDNissan V10.01 Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
PICKUP/N AVARA	D22	01/2008 01/1997	Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		

HDNissan **V10.01** Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
			Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	

HDNissan V10.01 Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
PRESAGE	U31	05/2007 05/2006 10/2004 06/2003 01/2005 02/2005	AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		

HDNissan **V10.01** Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
			Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
PRESAGE	U30	*	ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				

HDNissan **V10.01** Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
			Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
PRIMERA	P12	*	Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			

HDNissan **V10.01** Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
			Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
PRIMERA	P11	*	EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
			Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	

HDNissan V10.01 Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
PULSAR	N16	*	E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	

HDNissan **V10.01** Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
PULSAR	N15	* 01/1995	Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		

HDNissan **V10.01** Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
			Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	

HDNissan V10.01 Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
PULSAR WAGON	Y11	*	AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
			Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	

HDNissan V10.01 Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
SAFARI	Y61	*	ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				

HDNissan **V10.01** Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
			Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
SENTRA	B15	2006 2005 2004 2003 2002 2001 2000 *	Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			

HDNissan **V10.01** Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
			Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
SENTRA	B14	1999 1998 1997 1996 1995 *	EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
			Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	

HDNissan **V10.01** Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
SERENA	C24	*	E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
SKYLINE	V35	*	Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
			Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
SKYLINE	R34	*	AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		

HDNissan **V10.01** Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
			Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
SUNNY	B15	*	ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				

HDNissan **V10.01** Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
			Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
SUNNY	B14	*	Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
			Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			

HDNissan **V10.01** Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
SUNNY	Y10	*	EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
			Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	

HDNissan V10.01 Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
SUNNY	N16	*	E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	

HDNissan **V10.01** Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
SUNNY	N15	*	Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
			Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
SUNNY/ALMERA	N16	*	AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		

HDNissan V10.01 Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
			Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	

HDNissan V10.01 Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
SUNNY/ALMERA	N15	*	ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				

HDNissan **V10.01** Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
			Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			

HDNissan **V10.01** Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
SUNNY/ALMERA	N16	*	Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
			Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
TERRANO	WD21	*	EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
			Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
TERRANO	R50	*	HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			TCS	√	√	√	√	√	1.Work Support(*)	
TERRANO	R20	*	Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			

HDNissan **V10.01** Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
			Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
TERRANO /REGULUS	JR50	*	AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
			Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
TSURU/SENTRA	B13	*	ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				

HDNissan **V10.01** Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
			Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			

HDNissan **V10.01** Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
URVAN	E25	08/2007 01/2006 05/2003 07/2001 01/2006	Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
			Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			

HDNissan **V10.01** Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
WINGROAD	Y11	*	EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
			Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	

HDNissan **V10.01** Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
WINGROAD	Y10	*	E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	

HDNissan V10.01 Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
XTERRA	N50	2008 2007 2006 2005 07/2007 09/2005 01/2005	Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
		08/2007 09/2006	PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
			Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
XTERRA	WD22	2004 2003 2002 2001 2000 1999 *	AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		

HDNissan **V10.01** Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
			Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Freeze Frame(*) 4.IDLE AIR VOL LEARN(*)	
			AT	√	√	√	√	√	1.Calib Data (*) 2.Fuction test(*) 3.Work Support(*) 4.Freeze Frame(*)	

HDNissan **V10.01** Diagnostics List (Note: For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
X-TRAIL	T30	* 11/2007 10/2005 2006 2005 06/2001	ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.Can Diag(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			Airbag	√	√	√			1.Fuction test(*)	
			ICC	√	√	√	√			
			HVAC	√	√	√	√			
			MULTI AV	√	√	√	√	√	1.Work Support(*)	
			BAT CONT	√	√	√	√			
			EPS	√	√	√	√		1.Work Support(*)	
			IPDM	√	√	√	√	√		
			AIR PRESSURE MONITOR	√	√	√	√			
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)	
			E-4WD	√	√	√	√	√	1.Freeze Frame(*) 2.Can Diag Support Mntr (*)	
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			DIU		√	√	√			
			ASD	√	√	√	√	√		
			PRECRASH	√	√	√	√			
			AUTO DRIVER POS	√	√	√	√	√	1.Work Support(*)	
			4WD	√	√	√	√	√	1.Work Support(*)	
			4WAS/RAS/HICAS	√	√	√	√	√		
			SONAR		√	√	√			
			LDW	√	√	√	√	√	1.Work Support(*)	
			ADAPTIVE LIGHT	√	√	√	√		1.Work Support(*)	
			NATS IMMU	√	√	√				

HDNissan **V10.01** Diagnostics List (Note:For reference only)

Vehicle	Type	Date	System	Functions						
				Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
			SMART ENTRANCE		√	√	√	√	1.Work Support(*)	
			AIR LEVELIZER		√	√	√	√	1.Work Support(*)	
			REARVIEW CAMERA	√			√		1.Work Support(*)	
			SBLIND CAMERA	√			√		1.Work Support(*)	
			ACTIVE ENG MOUNT	√	√	√	√			
			ACTIVE SUS	√	√	√	√	√	1.Work Support(*)	
			ASCD		√	√	√			
			CHG COMM		√	√	√			
			TK_ECU_TYPE_CLUCH	√	√	√	√			
			DISTANCE CONTROL		√	√	√			
			MOTOR ASSIST		√	√	√		1.Work Support(*)	
			IVMS	√	√	√	√	√	1.Work Support(*)	
			TORQ CONT	√	√	√	√			
			TCS	√	√	√	√	√	1.Work Support(*)	
NOTE	E11	08/2009 12/2007	Engine	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*) 3.DTC&SRT CONFIRMATION	
			AT	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*)	
			ABS System	√	√	√	√	√	1.Fuction test(*) 2.Work Support(*)	
			BCM	√	√	√	√	√	1.Work Support(*)	
			METER		√	√	√			
			E-4WD	√	√	√	√	√		
			EPS	√	√	√	√			
			I-KEY	√	√	√	√	√	1.Work Support(*)	
			IPDM	√	√	√	√	√		

HDNissan V10.01 Diagnostics List(											
Vehicle	Type	Date	System	Functions							
				Sys. Info.	Read code	Clear code	Data Stream	Actuati on	Special Functions	Others	
			Airbag	√	√	√			1.Fuction test(*)		
			HEAD LAMP LEVELIZER	√	√	√	√	√	1.Work Support(*)		
(*) :Tested; (?) :Manual on website(www.x431.com) Note:The final interpretation of the products belongs to LAUNCH TECH CO.,LTD.											

Connector	Heavy Duty(980390*****)	Heavy Duty(980391*****)
OBDII -16C	OBDII -16C	SMART OBD II-16E
CANBUSII	OBDII -16C	SMART OBD II-16E
SUPER-16	SUPER-16	SMART OBD II-16E
NISSAN-14+16	NISSAN-14+16	NISSAN-14+16