CHRYSLER V28.17 **Diagnostics List**(Note:For reference only)

MAKE	MODEL	YEAR	PCM	TCM	ABS	AIRBAG	BCM	CCN	WCM	OCM	HVAC	SAS	SCM	EOM	AMP	PTS	RADIO	HFM	SDAR	ITM	DMFR	DMFL	PTCM	PEM	TPM	SCCM	IPC	RFH	EPS	ICS	BSM	TGW	VSIM	ADCM	AFLS	DTCM
	300M	98-02	CDVF	CDV	CDV	CDV	CDV																													
	300	05-06	CDVTFS1P	CDVTF S2	CDVTFS3	CDVF S4	CDVTF	CDV	CDVF	CDV	CDVTFS10P		CDVTFS10	CDVTF			CDV																			
		07	CDVTFS1P	CDVTF S2	CDVTFS3	CDVF S4	CDVTF S5P	CDVTF S6	CDVF	CDV	CDVTFS10P	CDVS10	CDVTFS10	CDVTF	CDVFS10P		CDV																			
		08	CDVTF S1P	CDVTF S2	CDVTFS3	CDVF S4	CDVTF S5P	CDVTF S6	CDVF S7	CDV	CDVTFS10P	CDVS10	CDVTFS10	CDVTF	CDVFS10P		CDV	CDVT	CDV	CDVF	CDVF	CDVT														
		09	CDVTF S1P	CDVTF S2	CDVTFS3	CDVF S4	CDVTF S5P	CDVTF S6	CDVF S7	CDV	CDVTFS10P	CDVS10	CDVTFS10	CDVTF	CDVFS10P		CDV	CDVT	CDV	CDVF	CDVF	CDVT														
		10	CDVTF S1P	CDVTF S2	CDVTFS3	CDVF S4	CDVTF S5P	CDVTF S6	CDVF S7	CDV	CDVTFS10P	CDVS10	CDVTFS10	CDVTF	CDVFS10P		CDV	CDVT	CDV	CDVF	CDVF	CDVT														
		11	CDVTF S1P	CDVFS18	CDVFS12	CDVF	CDVTF S5P	CDVTF S6	CDVF	CDV	CDVFS13P	CDV	CDVF	CDVF	CDVF		CDVS17	CDV	CDV	CDVFS14P	CDVF	CDV														
		12	CDVTF S1P	CDVF	CDVFS12	CDVF	CDVTF S5P	CDVTF S6	CDVF	CDV	CDVFS13P	CDV	CDVF	CDVF	CDVF		CDVS17	CDV	CDV	CDVFS14P	CDVF	CDV														
	ASPEN	07	CDVTF S1P	CDVTF S2		CDV	CDVTF S5P	CDVTF S6	CDVF	CDV	CDVTFS10P	CDVS10	CDVTFS10	CDVTF	CDVFS10P		CDV																			
		08	CDVTF S1P	CDVTF S2	CDVTFS3	CDVF S4	CDVTF S5P	CDVTF S6	CDVF S7	CDV	CDVTFS10P	CDVS10	CDVTFS10	CDVTF	CDVFS10P		CDV	CDVT	CDV	CDVF	CDVF	CDVT														
		09	CDVTF	CDVTF S2	CDVTFS3	CDVF S4	CDVTF S5P	CDVTF	CDVF S7	CDV	CDVTFS10P	CDVS10	CDVTFS1	CDVTF	CDVFS10P		CDV	CDVT	CDV	CDVF	CDVF	CDVT														
	CIRRUS	96-00	CDVF	CDV	CDV	CDV	CDV																													
	CONCORDE	02-04	CDV	CDV	CDV	CDV	CDV			CDV							CDV																			
	PACIFICA	04-06	CDVTF	CDVTF S2	CDVTF	CDVF	CDVTF S5P		CDV	CDV	CDVTFS10P						CDV																			
		07	CDVTF	CDVTF S2	CDVTFS3	CDVF S4	CDVTF S5P	CDVTF S6	CDVF S7	CDV	CDVTS10P	CDVS10	CDVTFS10	CDVTF	CDVFS10P	CDVTFS10P	CDV	CDVT	CDV	CDVF	CDVF	CDVT														
		08	CDVTF S1P	CDVTF S2	CDVTFS3	CDVF S4	CDVTF S5P	CDVTF S6	CDVF S7	CDV	CDVTS10P	CDVS10	CDVTFS10	CDVTF	CDVFS10P	CDVTFS10P	CDV	CDVT	CDV	CDVF	CDVF	CDVT														
	PT CRUISER	01-03	CDVT	CDV	CDVTF	CDV	CDV										CDV																			
		04-05	CDVT	CDVTF S2	CDVTFS3	CDV	CDV			CDV							CDV																			
		06-07	CDVTFS1P	CDVTF S2	CDVTFS3	CDVF S4	CDVTF S5P	CDVTF S6	CDVF	CDVT	CDVTFS10P	CDVS10	CDVTFS10	CDVTF			CDV																			

CHRYSLER V28.17 **Diagnostics List**(Note:For reference only)

MAKE	MODEL	YEAR	PCM	TCM	ABS	AIRBAG	BCM	CCN	WCM	OCM	HVAC	SAS	SCM	EOM	AMP	PTS	RADIO	HFM	SDAR	ITM	DMFR	DMFL	PTCM	PEM	TPM	SCCM	IPC	RFH	EPS	ICS	BSM	TGW	VSIM	ADCM	AFLS	DTCM
CHRYSLER		08	CDV TFS1	CDVT F S2	CDV TFS3	CDV F S4	CDVT F S5P	CDV TF	CDV F	CD VT		CDV S10	CDV TFS1	CDVT F	CDVF S10P		CDV	CDVT	CDV	CDVF	CDV F	CDVT														
		09	CDV TFS1	CDVT F S2	CDV TFS3	CDV F S4	CDVT F S5P	CDV TF	CDV F	CD VT		CDV S10	CDV TFS1	CDVT F	CDVF S10P		CDV	CDVT	CDV	CDVF	CDV F	CDVT														
		10	CDV TFS1	CDVT F S2	CDV TFS3	CDV F S4	CDVT F S5P	CDV TF	CDV F	CD VT		CDV S10	CDV TFS1	CDVT F	CDVF S10P		CDV	CDVT	CDV	CDVF	CDV F	CDVT														
	SEBRING	96-99	CDV T	CDV	CDV	CDV	CDV																													
		00-05	CDV T	CDV	CDV	CDV	CDV										CDV																			
		06-07	CDV TF S1P	CDVT F S2	CDV TFS3	CDV F S4	CDVT F S5P	CDV TF S6	CDV F	CD V	CDVT FS10P	CDV S10		CDVT F	CDVF S10P		CDV																			
		09	CDV TF S1P	CDVT F S2	CDV TFS3	CDV F S4	CDVT F S5P	CDV TF S6	CDV F	CD V	CDVT FS10P	CDV S10		CDVT F	CDVF S10P		CDV						CDVF S9													
		10	CDV TF S1P	CDVT F S2	CDV TFS3	CDV F S4	CDVT F S5P	CDV TF S6	CDV F	CD V	CDVT FS10P	CDV S10		CDVT F	CDVF S10P		CDV						CDVF S9													
		11	CDV TF S1P	CDVF S18	CDV FS12	CDV F	CDVT F S5P	CDV TF S6	CDV F	CD V	CDVF S13P	CDV		CDVF	CDVF		CDV S17						CDVF													
		12	CDV TF S1P	CDVF	CDV FS12	CDV F	CDVT F S5P	CDV TF S6	CDV F	CD V	CDVF S13P	CDV		CDVF	CDVF		CDV S17						CDVF													
	TOWN AND COUNTRY	99-00	CDV T	CDV	CDV	CDV	CDV																													
		01	CDV	CDV	CDV	CDV	CDV																													
		02-03	CDV	CDV	CDV	CDV	CDV										CDV																			
		04-05	CDV	CDV	CDV	CDV	CDV										CDV																			
		06-07	CDV	CDV	CDV TFS3	CDV F S4	CDVT	CDV TF				CDV S10	CDV TFS1	CDVT F	CDVF S10P		CDV																			
		08	CDV TF	CDVT F S2	CDV TFS3	CDV F S4	CDV	CDV TF	CDV	CD V	CDVT FS10P	CDV S10	CDV TFS1	CDVT F	CDVF S10P	CDV TFS1	CDVT	CDVT	CDV	CDVF	CDV F	CDVT														
		09	CDV TF	CDVT F S2	CDV TFS3	CDV F S4	CDVT F S5P	CDV TF	CDV F	CD VF	CDVT FS10P	CDV S10	CDV TFS1	CDVT F	CDVF S10P		CDV	CDVT	CDV	CDVF	CDV F	CDVT														

CHRYSLER V28.17 **Diagnostics List**(Note:For reference only)

MAKE	MODEL	YEAR	PCM	TCM	ABS	AIRBAG	BCM	CCN	WCM	OCM	HVAC	SAS	SCM	EOM	AMP	PTS	RADIO	HFM	SDAR	ITM	DMFR	DMFL	PTCM	PEM	TPM	SCCM	IPC	RFH	EPS	ICS	BSM	TGW	VSIM	ADCM	AFLS	DTCM
		10	CDVTF	CDVTF S2	CDVTFS3	CDVF S4	CDVTF S5P	CDVTF	CDVF	CDVF	CDVTFS10P	CDVS10	CDVTFS10	CDVTF	CDVFS10P		CDV	CDVT	CDV	CDVF	CDVF	CDVT														
		11	CDVTF	CDVFS18	CDVFS12	CDVF	CDVTF S5P	CDVTF	CDVF	CDVF	CDVFS13P	CDV	CDVF	CDVF	CDVF		CDVS17	CDV	CDV	CDVFS14P	CDVF	CDV														
		12	CDVTF	CDVF	CDVFS12	CDVF	CDVTF S5P	CDVTF	CDVF	CDVF	CDVFS13P	CDV	CDVF	CDVF	CDVF		CDVS17	CDV	CDV	CDVFS14P	CDVF	CDV														
	VOYAGER /GRAND VOYAGER	01	CDV	CDV	CDV	CDV	CDV																													
		02-03	CDV	CDV	CDV	CDV	CDV										CDV																			
		04	CDV	CDV	CDV	CDV	CDV										CDV																			
	AVENGER	96-05															CDV																			
		06-08	CDV	CDVTF S2	CDV	CDVF S4	CDVTF S5P	CDVTF S6	CDV	CDV	CDVTFS10P	CDVS10	CDVTFS10	CDVTF	CDVFS10P		CDV	CDVT	CDV	CDVF	CDVF	CDVT														
		09	CDVTF S1P	CDVTF S2	CDVTFS3	CDVF S4	CDVTF S5P	CDVTF S6	CDVF			CDVS10	CDVTFS10	CDVTF	CDVFS10P		CDV	CDVT	CDV	CDVF	CDVF	CDVT														
		10	CDVTF S1P	CDVTF S2	CDVTFS3	CDVF S4	CDVTF S5P	CDVTF S6	CDVF			CDVS10	CDVTFS10	CDVTF	CDVFS10P		CDV	CDVT	CDV	CDVF	CDVF	CDVT														
		11	CDVTF S1P	CDVFS18	CDVFS12	CDVF	CDVTF S5P	CDVTF S6	CDVF			CDV	CDVF	CDVF	CDVF		CDVS17	CDV	CDV	CDVFS14P	CDVF	CDV														
		12	CDVTF S1P	CDVF	CDVFS12	CDVF	CDVTF S5P	CDVTF S6	CDVF			CDV	CDVF	CDVF	CDVF		CDVS17	CDV	CDV	CDVFS14P	CDVF	CDV														
	CALIBER	07	CDV	CDVTF S2	CDVTFS3	CDVF S4	CDVTF S5P	CDVTF S6	CDV	CDV	CDVTFS10P	CDVS10	CDVTFS10	CDVTF	CDVFS10P		CDV																			
		08	CDV	CDVTF S2	CDVTFS3	CDVF S4	CDVTF S5P	CDVTF S6	CDV	CDV	CDVTFS10P	CDVS10	CDVTFS10	CDVTF	CDVFS10P		CDV	CDVT	CDV	CDVF	CDVF	CDVT														
		09	CDVTF	CDVTF S2	CDVTFS3	CDVF S4	CDVTF S5P	CDVTF S6	CDVF			CDVS10	CDVTFS10	CDVTF	CDVFS10P		CDV	CDVT	CDV	CDVF	CDVF	CDVT														
		10	CDVTF S1P	CDVTF S2	CDVTFS3	CDVF S4	CDVTF S5P	CDVTF S6	CDVF			CDVS10	CDVTFS10	CDVTF	CDVFS10P		CDV	CDVT	CDV	CDVF	CDVF	CDVT														
		11	CDVTF S1P	CDVFS18	CDVFS12	CDVF	CDVTF S5P	CDVTF S6	CDVF			CDV	CDVF	CDVF	CDVF		CDVS17	CDV	CDV	CDVFS14P	CDVF	CDV														

CHRYSLER V28.17 **Diagnostics List**(Note:For reference only)

MAKE	MODEL	YEAR	PCM	TCM	ABS	AIRBAG	BCM	CCN	WCM	OCM	HVAC	SAS	SCM	EOM	AMP	PTS	RADIO	HFM	SDAR	ITM	DMFR	DMFL	PTCM	PEM	TPM	SCCM	IPC	RFH	EPS	ICS	BSM	TGW	VSIM	ADCM	AFLS	DTCM
		12	CDV TF S1P	CDVF	CDV FS12	CDV F	CDVT F S5P	CDV TF S6	CDV F			CDV	CDV F	CDVF	CDVF		CDV S17	CDV	CDV	CDVF S14P	CDV F	CDV														
	CARAVAN /GRAND CARAVAN	96-00	CDV	CDV	CDV	CDV	CDV																													
		01-03	CDV	CDV	CDV	CDV	CDV										CDV																			
		04	CDV	CDV	CDV	CDV	CDV										CDV																			
		05	CDV	CDV	CDV	CDV	CDV					CDV					CDV																			
		06-07	CDV	CDVT F S2	CDV TFS3	CDV F S4	CDV	CDV TF S6				CDV S10	CDV TFS1 0	CDVT F	CDVF S10P		CDV																			
		08	CDV TF S1P	CDVT F S2	CDV TFS3	CDV F S4	CDV	CDV TF S6	CDV	CD V	CDVT FS10P	CDV S10	CDV TFS1 0	CDVT F	CDVF S10P		CDV	CDVT	CDV	CDVF	CDV F	CDVT														
		09	CDV TF S1P	CDVT F S2	CDV TFS3	CDV F S4	CDVT F	CDV TF S6	CDV F		CDVT FS10P	CDV S10	CDV TFS1 0	CDVT F	CDVF S10P		CDV	CDVT	CDV	CDVF	CDV F	CDVT														
		10	CDV TF S1P	CDVT F S2	CDV TFS3	CDV F S4	CDVT F S5P	CDV TF S6	CDV F		CDVT FS10P	CDV S10	CDV TFS1 0	CDVT F	CDVF S10P		CDV	CDVT	CDV	CDVF	CDV F	CDVT														
		11	CDV TF S1P	CDVF S18	CDV FS12	CDV F	CDVT F S5P	CDV TF S6	CDV F			CDV	CDV F	CDVF	CDVF		CDV S17	CDV	CDV	CDVF S14P	CDV F	CDV														
		12	CDV TF S1P	CDVF	CDV FS12	CDV F	CDVT F S5P	CDV TF S6	CDV F			CDV	CDV F	CDVF	CDVF		CDV S17	CDV	CDV	CDVF S14P	CDV F	CDV														
	CHALLENGER	08-09	CDV TF S1P	CDVT F S2	CDV TFS3	CDV F S4	CDVT F S5P	CDV TF S6	CDV F		CDVT FS10P	CDV S10	CDV TFS1 0	CDVT F	CDVF S10P		CDV	CDVT	CDV	CDVF	CDV F	CDVT		CDVF S10P												
		10	CDV TF S1P	CDVT F S2	CDV TFS3	CDV F S4	CDVT F S5P	CDV TF S6	CDV F		CDVT FS10P	CDV S10	CDV TFS1 0	CDVT F	CDVF S10P		CDV	CDVT	CDV	CDVF	CDV F	CDVT		CDVF S10P												
		11	CDV TF S1P	CDVF S18	CDV FS12	CDV F	CDVT F S5P	CDV TF S6	CDV F		CDVF S13P	CDV	CDV F	CDVF	CDVF		CDV S17	CDV	CDV	CDVF S14P	CDV F	CDV		CDVF S15												

CHRYSLER V28.17 **Diagnostics List**(Note:For reference only)

MAKE	MODEL	YEAR	PCM	TCM	ABS	AIRBAG	BCM	CCN	WCM	OCM	HVAC	SAS	SCM	EOM	AMP	PTS	RADIO	HFM	SDAR	ITM	DMFR	DMFL	PTCM	PEM	TPM	SCCM	IPC	RFH	EPS	ICS	BSM	TGW	VSIM	ADCM	AFLS	DTCM
DODGE		12	CDVTFS1P	CDVF	CDVFS12	CDVF	CDVTFS5P	CDVTFS6	CDVF		CDVFS13P	CDV	CDVF	CDVF	CDVF		CDVS17	CDV	CDV	CDVFS14P	CDVF	CDV		CDVFS15												
	CHARGER	06	CDVFTS1P	CDVTFS2	CDVTFS3	CDVFS4	CDVTFS5P										CDV																			
		07	CDVFTS1P	CDVTFS2	CDVTFS3	CDVFS4	CDVTFS5P	CDVTFS6				CDVS10	CDVTFS10	CDVTF	CDVFS10P		CDV																			
		08	CDVTFS1P	CDVTFS2	CDVTFS3	CDVFS4	CDVTFS5P	CDVTFS6	CDV	CDV	CDVTFS10P	CDVS10	CDVTFS10	CDVTF	CDVFS10P		CDV	CDVT	CDV	CDVF	CDVF	CDVT		CDVFS10P	CDVFS11											
		09	CDVTFS1P	CDVTFS2	CDVTFS3	CDVFS4	CDVTFS5P	CDVTFS6	CDV	CDV	CDVTFS10P	CDVS10	CDVTFS10	CDVTF	CDVFS10P		CDV	CDVT	CDV	CDVF	CDVF	CDVT		CDVFS10P	CDVFS11											
		10	CDVTFS1P	CDVTFS2	CDVTFS3	CDVFS4	CDVTFS5P	CDVTFS6	CDV	CDV	CDVTFS10P	CDVS10	CDVTFS10	CDVTF	CDVFS10P		CDV	CDVT	CDV	CDVF	CDVF	CDVT		CDVFS10P	CDVFS11											
		11	CDVTFS1P	CDVFS18	CDVFS12	CDVF	CDVTFS5P	CDVTFS6	CDVF	CDV	CDVFS13P	CDV	CDVF	CDVF	CDVF		CDVS17	CDV	CDV	CDVFS14P	CDVF	CDV		CDVFS15	CDVFS19											
		12	CDVTFS1P	CDVF	CDVFS12	CDVF	CDVTFS5P	CDVTFS6	CDVF	CDV	CDVFS13P	CDV	CDVF	CDVF	CDVF		CDVS17	CDV	CDV	CDVFS14P	CDVF	CDV		CDVFS15	CDVFS19											
	DAKOTA	96-99	CDV	CDV			CDV																													
		00-04	CDV	CDVT	CDVT	CDV	CDV			CDV							CDV																			
		05	CDVT	CDVTFS2	CDV	CDVTF	CDVTF	CDV	CDVF	CDV	CDVTF			CDVTF			CDV	CDVT	CDV	CDVF	CDVF	CDVT														
		06-09	CDVTFS1P	CDVTFS2	CDV		CDVTFS5P	CDVTFS6				CDVS10	CDVTFS10	CDVTF	CDVFS10P		CDV																			
		10	CDVTFS1P	CDVTFS2	CDV		CDVTFS5P	CDVTFS6				CDVS10	CDVTFS10	CDVTF	CDVFS10P		CDV																			
		11	CDVTFS1P	CDVFS18	CDVFS12		CDVTFS5P	CDVTFS6				CDV	CDVF	CDVF	CDVF		CDVS17																			
		12	CDVTFS1P	CDVF	CDVFS12		CDVTFS5P	CDVTFS6				CDV	CDVF	CDVF	CDVF		CDVS17																			
	DURANGO	98-01	CDV	CDV	CDVT	CDV	CDV																													
	DURANGO (NON-CAN)	02-04	CDV	CDV	CDV	CDV	CDV										CDV																			

CHRYSLER V28.17 **Diagnostics List**(Note:For reference only)

MAKE	MODEL	YEAR	PCM	TCM	ABS	AIRBAG	BCM	CCN	WCM	OCM	HVAC	SAS	SCM	EOM	AMP	PTS	RADIO	HFM	SDAR	ITM	DMFR	DMFL	PTCM	PEM	TPM	SCCM	IPC	RFH	EPS	ICS	BSM	TGW	VSIM	ADCM	AFLS	DTCM
	DURANGO (CAN)	04	CDVF	CDVTF	CDVF	CDVF	CDVF	CDV	CDVF	CDV	CDVTFS10P						CDV																			
	DURANGO	05-08	CDVTFS1P	CDVTFS2	CDVTFS3	CDVFS4	CDVTFS5P	CDVTFS6	CDVF	CDVF	CDVTFS10P	CDVS10	CDVTFS10	CDVTF	CDVFS10P		CDV	CDVT	CDV	CDVF	CDVF	CDVT														
		09	CDVTFS1P	CDVTFS2	CDVTFS3	CDVFS4	CDVTFS5P	CDVTFS6	CDV	CDV	CDVTFS10P	CDVS10	CDVTFS10	CDVTF	CDVFS10P		CDV	CDVT	CDV	CDVF	CDVF	CDVT														
	INTREPID	96-01	CDV	CDV	CDV	CDV																														
		02-03	CDV	CDV	CDV	CDV	CDV										CDV																			
		04	CDV	CDVT	CDVT	CDV	CDVT										CDV																			
	JOURNEY	08-09	CDVTFS1P	CDVTFS2	CDVTFS3	CDVFS4	CDVTFS5P	CDVTFS6	CDVF	CDVF	CDVTFS10P	CDVS10	CDVTFS10	CDVTF	CDVFS10P		CDV	CDVT	CDV	CDVF	CDVF	CDVT														
		10	CDVFTS1P	CDVTFS2	CDVTFS3	CDVFS4	CDVTFS5P	CDVTFS6	CDVF	CDVF	CDVTFS10P	CDVS10	CDVTFS10	CDVTF	CDVFS10P		CDV	CDVT	CDV	CDVF	CDVF	CDVT														
		11	CDVFTS1P	CDVFS18	CDVFS12	CDVF	CDVTFS5P	CDVTFS6	CDVF	CDVF	CDVFS13P	CDV	CDVF	CDVF	CDVF		CDVS17	CDV	CDV	CDVFS14P	CDVF	CDV														
		12	CDVFTS1P	CDVF	CDVFS12	CDVF	CDVTFS5P	CDVTFS6	CDVF	CDVF	CDVFS13P	CDV	CDVF	CDVF	CDVF		CDVS17	CDV	CDV	CDVFS14P	CDVF	CDV														
	MAGNUM	05	CDVTF	CDVTFS2	CDV	CDVFS4	CDVTFS5P	CDV	CDVF	CDV	CDVTFS10P						CDV																			
		06	CDVT	CDVTFS2	CDVTFS3	CDVFS4	CDVTFS5P	CDVTFS6	CDVF	CDV	CDVTFS10P	CDVS10	CDVTFS10	CDVTF			CDV																			
		07-08	CDVTFS1	CDVTFS2	CDVTFS3	CDVFS4	CDVTFS5P	CDVTFS6	CDVF	CDVF		CDVS10	CDVTFS10	CDVTF	CDVFS10P		CDV	CDVT	CDV	CDVF	CDVF	CDVT														
	NEON	96-03	CDV	CDV	CDV		CDV																													
		04-05	CDV	CDV	CDV		CDV										CDV																			
	NITRO	07-09	CDVTFS1P	CDVTFS2	CDV		CDV	CDVTFS6		CDVF		CDVS10	CDVTFS10	CDVTF	CDVFS10P		CDV	CDVT	CDV	CDVF	CDVF	CDVT														
		10	CDVTFS1P	CDVTFS2	CDV		CDV	CDVTFS6		CDVF		CDVS10	CDVTFS10	CDVTF	CDVFS10P		CDV	CDVT	CDV	CDVF	CDVF	CDVT														
		99	CDV	CDV			CDV																													

CHRYSLER V28.17 **Diagnostics List**(Note:For reference only)

MAKE	MODEL	YEAR	PCM	TCM	ABS	AIRBAG	BCM	CCN	WCM	OCM	HVAC	SAS	SCM	EOM	AMP	PTS	RADIO	HFM	SDAR	ITM	DMFR	DMFL	PTCM	PEM	TPM	SCCM	IPC	RFH	EPS	ICS	BSM	TGW	VSIM	ADCM	AFLS	DTCM
	RAM 1500	00	CDV	CDV	CDV	CDV	CDV																													
		01	CDV	CDV	CDV	CDV	CDV																													
		02-03	CDV	CDVT	CDVT	CDV	CDV										CDV																			
		04	CDV	CDVTF	CDV	CDV	CDV										CDV																			
		05	CDV	CDVTF	CDV	CDVF S4	CDV										CDV																			
		06	CDVTFP	CDVTF S2	CDVTFS3	CDVF S4	CDVTF S5P	CDV	CDVF	CDV	CDVTFS10P			CDVTF			CDV																			
	RAM 2500	04-06	CDVT	CDVTF	CDVF	CDV	CDV										CDV																			
		07-08	CDVTF S1P	CDVTF S2	CDVTFS3	CDVF S4	CDVTF S5P	CDVTF S6	CDVF	CDVF	CDVTS10P	CDVS10	CDVTFS10	CDVTF	CDVFS10P		CDV	CDVT	CDV	CDVF	CDVF	CDVT														
		09-10	CDVTF S1P	CDVTF S2	CDVTFS3	CDVF S4	CDVTF S5P	CDVTF S6	CDVF	CDVF	CDVTS10P	CDVS10	CDVTFS10	CDVTF	CDVFS10P		CDV	CDVT	CDV	CDVF	CDVF	CDVT														
		11	CDVTF S1P	CDVFS18	CDVFS12	CDVF	CDVTF S5P	CDVTF S6	CDVF	CDVF	CDVS13P	CDV	CDV	CDVF	CDVF		CDVS17	CDV	CDV	CDVFS14P	CDVF	CDV														
		12	CDVTF S1P	CDVF	CDVFS12	CDVF	CDVTF S5P	CDVTF S6	CDVF	CDVF	CDVS13P	CDV	CDV	CDVF	CDVF		CDVS17	CDV	CDV	CDVFS14P	CDVF	CDV														
	RAM 3500	04	CDV	CDV	CDV	CDV											CDV																			
		05-06	CDVTFP	CDVTF	CDV	CDVF S4	CDVTF S5P	CDV	CDVF	CDV	CDVTFS10P						CDV																			
		07-08	CDVTF S1P	CDVTF S2	CDV	CDVF S4	CDVTF S5P	CDVTF S6	CDV	CDVF	CDVTFS10P	CDVS10	CDVTFS10	CDVTF	CDVFS10P		CDVT	CDVT	CDV	CDVF	CDVF	CDVT														
		09-10	CDVTF S1P	CDVTF S2	CDV	CDVF S4	CDVTF S5P	CDVTF S6	CDV	CDVF	CDVTFS10P	CDVS10	CDVTFS10	CDVTF	CDVFS10P		CDVT	CDVT	CDV	CDVF	CDVF	CDVT														
		11	CDVTF S1P	CDVFS18	CDVFS12	CDVF	CDVTF S5P	CDVTF S6	CDVF	CDVF	CDVS13P	CDV	CDV	CDVF	CDVF		CDVS17	CDV	CDV	CDVFS14P	CDVF	CDV														
		12	CDVTF S1P	CDVF	CDVFS12	CDVF	CDVTF S5P	CDVTF S6	CDVF	CDVF	CDVS13P	CDV	CDV	CDVF	CDVF		CDVS17	CDV	CDV	CDVFS14P	CDVF	CDV														

CHRYSLER V28.17 **Diagnostics List**(Note:For reference only)

MAKE	MODEL	YEAR	PCM	TCM	ABS	AIRBAG	BCM	CCN	WCM	OCM	HVAC	SAS	SCM	EOM	AMP	PTS	RADIO	HFM	SDAR	ITM	DMFR	DMFL	PTCM	PEM	TPM	SCCM	IPC	RFH	EPS	ICS	BSM	TGW	VSIM	ADCM	AFLS	DTCM
	STEALTH	96	CDV	CDV	CDV	CDV	CDV																													
	STRATUS	01	CDV	CDV	CDV	CDV	CDV																													
		02-04	CDV	CDV	CDV	CDV	CDV										CDV																			
		05	CDV	CDV	CDV	CDV	CDV										CDV																			
	VIPER	96-06	CDV	CDV	CDV	CDV	CDV										CDV																			
		07-09	CDV TF S1P	CDVTF S2	CDV TFS3	CDV F S4	CDVTF S5P	CDV TF S6		CD VF	CDVS 10P	CDV S10	CDV TFS10	CDVTF	CDVF S10P	CDV TFS10P	VCS8	CDVT	CDV	CDVF	CDV F	CDVT														
		10	CDV TF S1P	CDVTF S2	CDV TFS3	CDV F S4	CDVTF S5P	CDV TF S6		CD VF	CDVS 10P	CDV S10	CDV TFS10	CDVTF	CDVF S10P	CDV TFS10P	VCS8	CDVT	CDV	CDVF	CDV F	CDVT														
		11	CDV TF S1P	CDVF S18	CDV FS12	CDV F	CDVTF S5P	CDV TF S6	CDV F	CD VF	CDVS 13P	CDV	CDV	CDVF	CDVF	CDV F S16	CDV S17	CDV	CDV	CDVF S14P	CDV F	CDV														
		12	CDV TF S1P	CDVF	CDV FS12	CDV F	CDVTF S5P	CDV TF S6	CDV F	CD VF	CDVS 13P	CDV	CDV	CDVF	CDVF	CDV F S16	CDV S17	CDV	CDV	CDVF S14P	CDV F	CDV														
	CHEROKEE	99	CDV	CDV	CDV		CDV																													
		00	CDV	CDV	CDV	CDV	CDV																													
		01	CDV	CDV	CDV	CDV	CDV																													
		02	CDV	CDV	CDV	CDV	CDV																													
		03	CDV	CDV	CDV	CDV	CDV										CDV																			
		04	CDV	CDV	CDV	CDV	CDV										CDV																			
		06	CDV	CDVTF	CDV TFS3	CDV F S4	CDVTF S5P	CDV	CDV	CD V	CDVT FS10P						CDV																			
		07	CDV TFP	CDVTF S2	CDV TFS3	CDV F S4	CDVTF S5P	CDV TF S6		CD VF		CDV S10	CDV TFS10	CDVTF	CDVF S10P		CDV																			
		08	CDV TF S1P	CDVTF S2	CDV TFS3	CDV F S4	CDVTF S5P	CDV TF S6	CDV F	CD VF	CDVT FS10P	CDV S10	CDV TFS10	CDVTF	CDVF S10P	CDV TFS10P	CDV	CDVT	CDV	CDVF	CDV F	CDVT														

CHRYSLER V28.17 **Diagnostics List**(Note:For reference only)

MAKE	MODEL	YEAR	PCM	TCM	ABS	AIRBAG	BCM	CCN	WCM	OCM	HVAC	SAS	SCM	EOM	AMP	PTS	RADIO	HFM	SDAR	ITM	DMFR	DMFL	PTCM	PEM	TPM	SCCM	IPC	RFH	EPS	ICS	BSM	TGW	VSIM	ADCM	AFLS	DTCM
	COMMANDER	09	CDV TF S1P	CDVT F S2	CDV TFS3	CDV F S4	CDVT F S5P	CDV TF S6		CD VF		CDV S10	CDV TFS10	CDVT F	CDVF S10P		CDV	CDVT	CDV	CDVF	CDV F	CDVT														
		10	CDV TF S1P	CDVT F S2	CDV TFS3	CDV F S4	CDVT F S5P	CDV TF S6		CD VF		CDV S10	CDV TFS10	CDVT F	CDVF S10P		CDV	CDVT	CDV	CDVF	CDV F	CDVT														
		11	CDV TF S1P	CDVF S18	CDV FS12	CDV F	CDVT F S5P	CDV TF S6		CD VF		CDV	CDV F	CDVF	CDVF		CDV S17	CDV	CDV	CDVF S14P	CDV F	CDV														
		12	CDV TF S1P	CDVF	CDV FS12	CDV F	CDVT F S5P	CDV TF S6		CD VF		CDV	CDV F	CDVF	CDVF		CDV S17	CDV	CDV	CDVF S14P	CDV F	CDV														
	COMPASS	07	CDV TF S1P	CDVT F S2	CDV TFS3	CDV F S4	CDVT F S5P	CDV TF S6	CDV	CD VF	CDVT FS10P	CDV S10	CDV TFS10	CDVT F	CDVF S10P		CDV																			
		08	CDV TF S1P	CDVT F S2	CDV TFS3	CDV F S4	CDVT F S5P	CDV TF S6	CDV	CD VF	CDVT FS10P	CDV S10	CDV TFS10	CDVT F	CDVF S10P		CDV	CDVT	CDV	CDVF	CDV F	CDVT														
		09	CDV TF S1P	CDVT F S2	CDV TFS3	CDV F S4	CDVT F S5P	CDV TF S6		CD VF		CDV S10	CDV TFS10	CDVT F	CDVF S10P		CDV	CDVT	CDV	CDVF	CDV F	CDVT														
		10	CDV TF S1P	CDVT F S2	CDV TFS3	CDV F S4	CDVT F S5P	CDV TF S6		CD VF		CDV S10	CDV TFS10	CDVT F	CDVF S10P		CDV	CDVT	CDV	CDVF	CDV F	CDVT														
		11	CDV F	CDVF S18	CDV FS12	CDV F	CDVT F S5P	CDV TF S6		CD VF		CDV	CDV F	CDVF	CDVF		CDV S17	CDV	CDV	CDVF S14P	CDV F	CDV														
	GRAND CHEROKEE	05	CDV TF	CDVT F	CDV F	CDV F S4	CDVT F S5P	CDV	CDV	CD V	CDVT FS10P	CDV	CDV TFS1				CDV																			
		06	CDV TF	CDVT F	CDV TFS3	CDV F S4	CDVT F S5P	CDV		CD VF		CDV S10	CDV TFS1				CDV																			
		07	CDV TF	CDVT F S2	CDV TFS3	CDV F S4	CDVT F S5P	CDV TF	CDV	CD VF	CDVT FS10P	CDV S10	CDV TFS1	CDVT F	CDVF S10P		CDV																			
		08	CDV TF	CDVT F S2	CDV TFS3	CDV F S4	CDVT F S5P	CDV TF	CDV	CD VF	CDVT FS10P	CDV S10	CDV TFS1	CDVT F	CDVF S10P		CDV	CDVT	CDV	CDVF	CDV F	CDVT														
		09	CDV TF S1P	CDVT F S2	CDV TFS3	CDV F S4	CDVT F S5P	CDV TF S6		CD VF		CDV S10	CDV TFS10	CDVT F	CDVF S10P		CDV	CDVT	CDV	CDVF	CDV F	CDVT														
		10	CDV TF S1P	CDVT F S2	CDV TFS3	CDV F S4	CDVT F S5P	CDV TF S6		CD VF		CDV S10	CDV TFS10	CDVT F	CDVF S10P		CDV	CDVT	CDV	CDVF	CDV F	CDVT														
		11	CDV TF S1P	CDVF S18	CDV FS12	CDV F	CDVT F S5P	CDV TF S6		CD VF		CDV	CDV F	CDVF	CDVF		CDV S17	CDV	CDV	CDVF S14P	CDV F	CDV														

CHRYSLER V28.17 **Diagnostics List**(Note:For reference only)

MAKE	MODEL	YEAR	PCM	TCM	ABS	AIRBAG	BCM	CCN	WCM	OCM	HVAC	SAS	SCM	EOM	AMP	PTS	RADIO	HFM	SDAR	ITM	DMFR	DMFL	PTCM	PEM	TPM	SCCM	IPC	RFH	EPS	ICS	BSM	TGW	VSIM	ADCM	AFLS	DTCM
Jeep		12	CDV TF S1P	CDVF	CDV FS12	CDV F	CDVT F S5P	CDV TF S6		CD VF		CDV	CDV F	CDVF	CDVF		CDV S17	CDV	CDV	CDVF S14P	CDV F	CDV														
	LIBERTY	02	CDV	CDV	CDV	CDV	CDV																													
		03	CDV	CDV	CDV	CDV	CDV										CDV																			
	LIBERTY(EXCEPT DIESEL)	04	CDV	CDV	CDV	CDV	CDV										CDV																			
		05	CDV	CDVT	CDV	CDV	CDV										CDV																			
		06-07	CDV TF S1P	CDVT F S2	CDV TFS3	CDV F S4	CDVT F S5P	CDV TF S6		CD VF		CDV S10	CDV TFS10	CDV	CDVF S10P		CDV	CDVT	CDV	CDVF	CDV F	CDVT														
		08	CDV TF S1P	CDVT F S2	CDV TFS3	CDV F S4	CDVT F S5P	CDV TF S6		CD VF		CDV S10	CDV TFS10	CDVT F	CDVF S10P		CDV	CDVT	CDV	CDVF	CDV F	CDVT														
		09	CDV TF S1P	CDVT F S2	CDV TFS3	CDV F S4	CDVT F S5P	CDV TF S6		CD VF		CDV S10	CDV TFS10	CDVT F	CDVF		CDV	CDVT	CDV	CDVF	CDV F	CDVT														
		10	CDV TF S1P	CDVT F S2	CDV TFS3	CDV F S4	CDVT F S5P	CDV TF S6		CD VF		CDV S10	CDV TFS10	CDVT F	CDVF S10P		CDV	CDVT	CDV	CDVF	CDV F	CDVT														
		11	CDV TF S1P	CDVF S18	CDV FS12	CDV F	CDVT F S5P	CDV TF S6		CD VF		CDV	CDV F	CDVF	CDVF		CDV S17	CDV	CDV	CDVF S14P	CDV F	CDV														
		12	CDV TF S1P	CDVF	CDV FS12	CDV F	CDVT F S5P	CDV TF S6		CD VF		CDV	CDV F	CDVF	CDVF		CDV S17	CDV	CDV	CDVF S14P	CDV F	CDV														
	PATRIOT	07	CDV TF S1P	CDVT F S2	CDV TFS3	CDV	CDVT F S5P	CDV TF S6				CDV S10	CDV TFS10	CDVT F	CDVF S10P		CDV																			
		08	CDV TF	CDVT F S2	CDV TFS3	CDV F S4	CDVT F S5P	CDV TF	CDV F			CDV S10	CDV TFS1	CDVT F	CDVF S10P		CDV	CDVT	CDV	CDVF	CDV F	CDVT														
		09	CDV TFS1P	CDVT F S2	CDV TFS3	CDV F S4	CDVT F S5P	CDV TF S6				CDV S10	CDV TFS10	CDVT F	CDVF S10P		CDV	CDVT	CDV	CDVF	CDV F	CDVT														
		10	CDV TFS1P	CDVT F S2	CDV TFS3	CDV F S4	CDVT F S5P	CDV TF S6				CDV S10	CDV TFS10	CDVT F	CDVF S10P		CDV	CDVT	CDV	CDVF	CDV F	CDVT														
		11	CDV TFS1P	CDVF S18	CDV FS12	CDV F	CDVT F S5P	CDV TF S6				CDV	CDV F	CDVF	CDVF		CDV S17	CDV	CDV	CDVF S14P	CDV F	CDV														

CHRYSLER V28.17 **Diagnostics List**(Note:For reference only)

MAKE	MODEL	YEAR	PCM	TCM	ABS	AIRBAG	BCM	CCN	WCM	OCM	HVAC	SAS	SCM	EOM	AMP	PTS	RADIO	HFM	SDAR	ITM	DMFR	DMFL	PTCM	PEM	TPM	SCCM	IPC	RFH	EPS	ICS	BSM	TGW	VSIM	ADCM	AFLS	DTCM
		12	CDVTFS1P	CDVF	CDVFS12	CDVF	CDVTF S5P	CDVTF S6				CDV	CDVF	CDVF	CDVF		CDVS17	CDV	CDV	CDVFS14P	CDVF	CDV														
	WRANGLER	97-98	CDV	CDV	CDV	CDV	CDV																													
		99	CDV	CDV	CDV	CDV	CDV																													
		00-02	CDV	CDV	CDV	CDV	CDV																													
		03-04	CDV	CDV	CDVF	CDV	CDV																													
		05	CDV	CDV	CDVF	CDV	CDVTF S5P										CDV																			
		06	CDVTF S1P	CDVTF	CDVTFS3	CDVF S4	CDVTF S5P										CDV																			
		07	CDVTF S1P	CDVTF S2	CDVTFS3	CDVF S4	CDVTF S5P	CDVTF S6	CDVF	CDV	CDVTFS10P	CDVS10	CDVTFS10	CDVTF	CDVFS10P		CDV																			
		08	CDVTF S1P	CDVTF S2	CDVTFS3	CDVF S4	CDVTF S5P	CDVTF S6	CDVF	CDV	CDVTFS10P	CDVS10	CDVTFS10	CDVTF	CDVFS10P		CDV	CDVT	CDV	CDVF	CDVF	CDVT														
		09	CDVTFS1P	CDVTF S2	CDVTFS3	CDVF S4	CDVTF S5P	CDVTF S6	CDVF	CDV	CDVTFS10P	CDVS10	CDVTFS10	CDVTF	CDVFS10P	CDVTFS10P	CDV	CDVT	CDV	CDVF	CDVF	CDVT														
		10	CDVTFS1P	CDVTF S2	CDVTFS3	CDVF S4	CDVTF S5P	CDVTF S6	CDVF	CDV	CDVTFS10P	CDVS10	CDVTFS10	CDVTF	CDVFS10P	CDVTFS10P	CDV	CDVT	CDV	CDVF	CDVF	CDVT														
		11	CDVTFS1P	CDVFS18	CDVFS12	CDVF	CDVTF S5P	CDVTF S6	CDVF	CDV	CDVFS13P	CDV	CDVF	CDV	CDVF	CDVF S16	CDVS17	CDV	CDV	CDVFS14P	CDVF	CDV														
		12	CDVTFS1P	CDVF	CDVFS12	CDVF	CDVTF S5P	CDVTF S6	CDVF	CDV	CDVFS13P	CDV	CDVF	CDV	CDVF	CDVF S16	CDVS17	CDV	CDV	CDVFS14P	CDVF	CDV														
Note:																																				
C:	DTC																																			
D:	Data Display																																			
V:	System Version Info																																			
T:	Action Test																																			
F:	Configure Info																																			
P:	System Test																																			
S1	Reset ECU																																			
S1	Overdrive Switch Test,																																			
S1	Thermistor Test																																			
S1	Enable Emissions Rolls Test Mode																																			

CHRYSLER V28.17 **Diagnostics List**(Note:For reference only)

MAKE	MODEL	YEAR	PCM	TCM	ABS	AIRBAG	BCM	CCN	WCM	OCM	HVAC	SAS	SCM	EOM	AMP	PTS	RADIO	HFM	SDAR	ITM	DMFR	DMFL	PTCM	PEM	TPM	SCCM	IPC	RFH	EPS	ICS	BSM	TGW	VSIM	ADCM	AFLS	DTCM
S1	Check PCM Odometer																																			
S1	Check PCM VIN																																			
S1	Learn ETC																																			
S1	Reset Memory																																			
S1	Clear Variable Line Pressure(VLP) Counters																																			
S1	Quick Learn																																			
S1	Relearn Cam/Crank																																			
S1	Injector Quantity Adjustment																																			
S1	View/Reset duty cycle accumulators																																			
S1	View/reset trip information accumulators																																			
S1	Enable / Disable vehicle features																																			
S1	Reset Nox adsorber counts																																			
S1	Reset aftertreatment trip information																																			
S1	turbo actuator pre-align / self calibrate																																			
S1	reset regenerative filter timers																																			
S1	20% Biodiesel water in fuel kit enable																																			
S1	Reset Fuel Pressure Limiting Valve Accumulators																																			
S1	Stationary Desoot																																			
S1	View/Reset Duty Cycle Maps																																			
S1	Idle Shutdown Timer Adjustment																																			
S1	Oil Change Monitor Type																																			
S1	View/Reset NAC After Treatment Over Temp Events																																			
S1	Manual DPF Regeneration																																			
S1	DPF Replacement																																			
S1	ECM Replacemen																																			
S2	TCC Break-In																																			
S2	Initialize CVT																																			
S2	TCM Store Adaptive																																			
S2	Thermistor test																																			
S2	Overdrive Switch test																																			
S2	Reset ECU																																			
S2	Initialize EGS-52/53																																			
S2	Quick Learn																																			
S2	Clear Variable line pressure(VLP) counters																																			
S2	Reset Learned Adaptives																																			
S2	Store Learned Adaptives																																			
S3	Reset ECU																																			
S3	Bleed Brakes																																			
S3	Initialize ECU																																			
S4	Reset ECU																																			
S4	Initialize ORC																																			
S4	Rollover Detection																																			
S5	Horn Chirp Duration																																			
S5	Illuminated Entry Time																																			

CHRYSLER V28.17 **Diagnostics List**(Note:For reference only)

MAKE	MODEL	YEAR	PCM	TCM	ABS	AIRBAG	BCM	CCN	WCM	OCM	HVAC	SAS	SCM	EOM	AMP	PTS	RADIO	HFM	SDAR	ITM	DMFR	DMFL	PTCM	PEM	TPM	SCCM	IPC	RFH	EPS	ICS	BSM	TGW	VSIM	ADCM	AFLS	DTCM
S5	Flash Hazard Lamps On Lock																																			
S5	Accessory Delay Time																																			
S5	Enable DRL																																			
S5	Temporary Tip Start Disable																																			
S5	Enable Front Fog Lamp Output																																			
S5	Disable Radio Clock Display																																			
S5	Change Country Code																																			
S5	Sound Horn On lock																																			
S5	Headlamps On with wipers																																			
S5	Trailer Tow Relay Outputs																																			
S5	Add Navigation Radio																																			
S5	Headlamps Delay Time																																			
S5	Auto Wipers																																			
S5	Program Network Configuration																																			
S5	Unlock All Doors First Press																																			
S5	Auto Door Lock																																			
S5	Auto Door Unlock																																			
S5	Headlamps on with Wipers																																			
S5	Actuate Engine Battery Feed																																			
S5	Actuate Transmission Relay																																			
S5	Program Tire Size																																			
S6	Unlock Driver Door On 1st Press																																			
S6	Service Interval – Diesel																																			
S6	Service Interval – Gas																																			
S6	change Measurement unit																																			
S6	Auto door unlock																																			
S6	Auto door lock																																			
S6	Lauguage preference																																			
S6	Seatbelt alert system																																			
S6	Reset ECU																																			
S6	Measurement Unit																																			
S6	Turn by Turn Navigation																																			
S7	Program Right Rear Tire Sensor ID																																			
S7	Program Left Front Tire Sensor ID																																			
S7	Program Left Rear Tire Sensor ID																																			
S7	Program Right Front Tire Sensor ID																																			
S7	Program Spare Tire Sensor ID																																			
S7	Reset ECU																																			
S7	TPM Trigger Module Test																																			
S8:	Reset to default parameters																																			
S8:	Enable/Disable Front Seat Video																																			
S8:	Reset ECU																																			
S9:	Reset ECU																																			
S9:	Reset Power Top Control Module																																			

CHRYSLER V28.17 **Diagnostics List**(Note:For reference only)

MAKE	MODEL	YEAR	PCM	TCM	ABS	AIRBAG	BCM	CCN	WCM	OCM	HVAC	SAS	SCM	EOM	AMP	PTS	RADIO	HFM	SDAR	ITM	DMFR	DMFL	PTCM	PEM	TPM	SCCM	IPC	RFH	EPS	ICS	BSM	TGW	VSIM	ADCM	AFLS	DTCM
S9:	Manual Top Movement																																			
S9:	Right Rear window movement																																			
S9:	Left Rear window movement																																			
S10	Reset ECU																																			
S11	Reset ECU																																			
S11	Program Left Front Tire Sensor ID																																			
S11	Program Left Rear Tire Sensor ID																																			
S11	Program Right Rear Tire Sensor ID																																			
S11	Program Right Front Tire Sensor ID																																			
S11	TPM Sensor Test																																			
S12	ABS Bleed Brakes																																			
S13	Reset ECU																																			
S13	Most Recent Cool down Test Results																																			
S13	First Passed Cool down Test Results																																			
S14	Reset ECU																																			
S14	Initialize Siren																																			
S14	ITM Initialize																																			
S14	ITM Initialize Siren																																			
S14	ITM Siren Communication																																			
S14	Initialize ITM and Siren																																			
S15	Door Handle Verification Test																																			
S15	LF Antenna Verification Test																																			
S15	Locate Learned keys																																			
S15	PEM Replace																																			
S16	Configure PTS																																			
S17	Enable/Disable Front Seat Video																																			
S17	Radio Tone Test																																			
S17	Radio Hard-drive Back-up																																			
S18	Learn Clutches Contact Point																																			
S18	Quick Learn																																			
S18	Reset of Data group																																			
S18	New Actuators																																			
S18	Bleed Hydraulic Circuit																																			
S18	Hydraulic Circuit depressurization																																			
S18	Trans Adapt Reset Trigger																																			
S18	Check TCM VIN																																			
S18	Trans Cleaning Procedure																																			
S19	Reset ECU																																			
S19	program Left Front Tire Sensor ID																																			
S19	Program Left Rear Tire Sensor ID																																			
S19	program Right Front Tire Sensor ID																																			
S19	Program Right Rear Tire Sensor ID																																			
S19	Program Tire Sensor ID with TPM Tool																																			
S19	TPM Sensor Rolls Test																																			